

## INCLUDED IN THE PACKAGE

- PowerBank PB7: 20100 mAh/72.9 Wh Rechargeable Lithium Ion Battery, Two outputs, USB-A=5V/2.4A and USB-C=5V/3.0A, Input USB-A=5V/2.4A and USB-C=5V/3.0A
  - 1 USB-C
  - 1 microUSB cable
  - 1 Quick Start Instruction Card

## COMPATIBILITY

Duracell PowerBanks (hereinafter “Product(s)”) are compatible with most smart phones, tablets, computers and other USB powered devices.

## SAFETY & SUPPORT

### IMPORTANT SAFETY INSTRUCTIONS

WARNING – When using the Product, basic precautions should always be followed:

- a) Read all the instructions before using the Product.
- b) To reduce the risk of injury, close supervision is necessary when the Product is used near children.
- c) Do not expose the Product to rain or snow.
- d) Use of a faulty charger to charge the Product may result in a risk of fire or injury to persons.
- e) Do not use the product in excess of its output rating. Overloaded outputs above the output rating may result in a risk of fire or injury to persons.
- f) Do not use the Product if it is damaged or modified. Damage or modification of the Product, including the lithium ion batteries within the Product, may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- g) Do not disassemble the Product.
- h) Do not expose the Product to fire or excessive temperature. Any such exposure to fire or temperature above 140°F (60°C) may cause explosion.
- i) This product has no serviceable parts. Please visit [www.duracell.com](http://www.duracell.com) or call Duracell Consumer Relations at 800-551-2355 if you experience any problems with the Product.
- j) Do not use the Product where aerosol (spray) products are being used or where oxygen is being administered.
- k) Only set or store the Product on clean, dry surfaces. Do not place the Product on any surface that is wet from water or cleaning solvents.
- l) Do not operate the Product in a closed environment, such as a pocket, backpack or carry case.

### SAVE THESE INSTRUCTIONS

DURACELL guarantees your satisfaction. If not completely satisfied with your product, please visit [www.duracell.com](http://www.duracell.com) or call Duracell Consumer Relations at 1-800-551-2355 (9am- 5pm EST).

Do not return this unit to the authorized reseller. Please visit [www.duracell.com](http://www.duracell.com) or call Duracell Consumer Relations for questions or concerns involving service or repair.

### PRODUCT SAFETY INFORMATION

- Do not dismantle, open or shred the Product.
- Do not expose the Product to heat or fire
- Avoid storage of the Product in direct sunlight.
- Do not short-circuit the Product.
- Do not subject the Product to mechanical shock.
- Keep the Product out of the reach of children.
- Keep the Product clean and dry.
- Do not leave the Product on prolonged charge when not in use.

### PRODUCT STORAGE

- Store the Product in a cool dry place.
- Store the Product when charged at regular ambient temperatures, 77°F ± 41°F (25°C ± 5°C)

### PRODUCT CAUTION

The lithium ion rechargeable battery used in the Product may present a risk of fire or chemical burn if mistreated. Do not disassemble, short circuit, crush, expose to heat above 140°F (60°C), or incinerate the Product. Do not operate the Product outside of its operating temperature range of 32°F to 104°F (0°C to 40°C) Misusing or incorrectly connecting the Product may cause electric shock to users and damage equipment. Read instructions carefully. The Product may become warm and may reach 122°F (50°C) under extended


high-power operation. During operation, keep the Product away from materials that may be affected by these temperatures. Follow manufacturer instructions.

Recycle the Product responsibly and according to local, state, and national regulations applicable to lithium ion rechargeable batteries.

Devices sold separately.

## INSTRUCTIONS:


1



2



3



## ENGLISH

1. Charging your Duracell PowerBank ( using either the microUSB cable or a USB-C cable)
2. Charging your device ( plug your phone cable to either the USB-A or the USB-C port)
3. Power/Battery indicator